

22 Inch TFT Color Display



Operating Instructions

© 2007

All rights reserved.

This manual is protected by Copyright.

The Copyright is owned by **Medion®**.

Trademarks:

MS-DOS® and **Windows®** are registered trademarks of **Microsoft®**.

Pentium® is a registered trademark of **Intel®**.

Other trademarks are the property of their respective owners.

Medion® makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Medion® shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Medion® assumes no responsibility for the use or reliability of its software on equipment that is not furnished by **Medion®**.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of **Medion®**.

The information in this document is subject to change without notice.

Contents:

Notes on these instructions	1
Our Target Group	1
Quality	1
Service	1
Purpose of use	1
Included Equipment	1
Safety and Precautions	2
Operating Safety	2
Point of use	2
Repair	2
Intended Environment	2
Power Supply	3
Standards/Electro-Magnetic Compatibility	3
Ergonomics	3
Electrical Safety	3
Important Additional Safety Instructions	3
FCC Compliance Statement	4
Declaration of Conformity	4
Start-Up	5
Mounting the Display Stand	5
Preparations on Your Computer	5
Supported Display Settings	5
Display Properties	6
Connecting the Display	7
❶ Connecting Signal Cable	7
❷ Connecting Audio Cable	7
❸ Connecting the Power Supply	7
Positioning of the Display	8
Your posture	8
Working Ergonomics	9
Controls	10
Setting the TFT Display	11
How to operate the OSD menu	11
Leaving the OSD menu	11
OSD Menu	11
Picture	12
Advanced	12
Audio	13
Options	13
Utilities	13
Reset	13
Saving Energy	14
Service	15
Troubleshooting	15
Finding the problem	15
Check Connections and Cables	15
Troubleshooting	15
Do you require additional Support?	16
Precautions	17
Recycling	17
Specifications	17
Restricted Warranty	18
Copying this manual	20
Recycling Information	21
TCO Development	23
Congratulations!	23
Ergonomics	23
Energy	23
Emissions	23
Ecology	23
Pixel Defects on TFTs (LCD-Displays)	24

Notes on these instructions

Please read through these operating instructions carefully and follow the instructions given. In this way you will guarantee reliable operation and a long life for your TFT display. Always keep these instructions handy and close by your TFT display. Keep the instructions and the packaging so that if you sell or give away your TFT display you can give them to the new owner.

We have arranged these instructions so that you can quickly find the subject related information in the table of contents. The purpose of these instructions is helping you operate your TFT display safely, quickly and easily.

Our Target Group

These instructions are intended for initial users as well as advanced users.

Quality

We focused on great features, ease of use and reliability in manufacturing your TFT display. The balanced hardware and software concept offers you an advanced display design which will provide you a great deal of pleasure for your work and entertainment.

Thank you for your confidence in our products. We are pleased to welcome you as a new customer.

Service

Service and support will be available every time you use your new TFT Display. Contact us, we will be glad to help. This manual contains a separate chapter on the subject of service beginning on page 15.

Purpose of use

- This device is only suitable for use **in dry, interior rooms**.
- This device is only intended for **private use**. The device **is not** intended for operation in a **heavily industrial company**. Use of the device under extreme environmental condition can result in damage to it.

Included Equipment

Please check your new TFT Display for completeness. Notify **us within 14 days after purchase** if it is not complete. With your TFT display you receive:

- 1 - TFT display
- 1 - Connection cable
- 1 - 15-wired Sub-D cable
- 1 - DVI-D cable
- 1 - Audio cable
- 1 - Stand
- 1 - Guarantee card
- 1 - Operating instructions

Safety and Precautions

Operating Safety

- Do not allow children to play unattended on electrical equipment. Children may not always correctly recognize danger.
- Keep the packing materials, such as **foil away from children**. The **danger of suffocation** could arise in the case of misuse.
- Never open the housing of the TFT display (electric shock, short-circuit and the danger of fire)!
- Do not insert **any objects** through the slots and openings **into the inside of the TFT** (electrical shock, short-circuit and the danger of fire)!
- Slots and openings in the TFT display are for ventilation purpose. **Do not cover these openings**, as otherwise this may lead to overheating (overheating, danger of fire)!
- Never exert pressure on the display. This could break the display.
- An injury hazard exists when the display breaks. Wear protective gloves to pack the broken parts and send them into your service center for proper disposal. Then wash your hands with soap, because it is possible for chemicals to escape.
- Do not touch the display with your fingers or with sharp objects to avoid damage.

Please proceed as outlined in the **Customer Service** section:

- if the power cable overheats or is damaged
- if liquid has gotten into the display
- if the TFT display is dropped or the housing damaged

Point of use

- In the first hours of operation, new devices may emit a typical, unavoidable but completely harmless smell, which will decline increasingly in the course of time.
We recommend you to ventilate the room regularly, in order to counteract the formation of the smell. During the development of this product, we have made sure that the applicable limits are clearly fallen below.
- Keep your TFT display and all units connected to it away from moisture and avoid dust, heat and direct sunlight. Failure to observe these instructions can lead to malfunctions or damage to the TFT display.
- Do **not** operate your device **in the open air**, because external influences, such as rain, snow, etc. could damage the device.
- Do **not** place **any containers filled with liquid** (vases or similar containers) **on the device**. The container could tip over and liquid can impair electrical safety.
- Do **not** place **any open sources of fire** (candles or similar objects) **on the device**.
- Pay attention to **sufficiently large clearances** in the wall cupboard. Maintain a **minimum clearance of 10 cm around the device** for sufficient ventilation.
- Place and operate all units on a **stable, level and vibration-free surface** in order to avoid the TFT display from falling.
- **Avoid dazzle, reflections, extreme light/dark contrast** in order to save your eyes and ensure a pleasant, ergonomic work station.
- Take **regulator breaks** when working with your TFT display in order to avoid tension and fatigue.

Repair

- Leave all repairs of your TFT display to authorized and qualified personnel only.
- Should a repair be necessary, please contact one of our authorized **service partners** only.

Intended Environment

- The TFT display can be operated at an ambient temperatures of between **+41°F** and **+95°F** (5° C to 35° C) and at a relative humidity of between 20% and 85% (without condensation).
- When switched off, the display can be stored at between **-4°F** and **+140°F** (-20° C - +60° C), up to the maximum height of 39,000 ft (12,000 m) above sea level at a relative humidity of between 20% and 80% (without condensation).
- After transporting your TFT display please wait until it has assumed the ambient temperature before connecting and switching it on. Extremely high variations in the **temperature or humidity** may result in condensation forming on the inside of the TFT display which could cause an **electrical short-circuit**.

Power Supply



Please pay attention: Parts of the device are still live, even if the mains switch is switched off. **Pull the mains plug** out of the socket, to interrupt the power supply to your TFT display or to release the device from voltage completely.

- Operate your TFT display mains (power supply) only on grounded sockets with **AC 100-240V~/ 50-60 Hz**. If you are not sure about the power supply at your location, check with your power company.
- For additional safety we recommend use of **an excessive voltage protection device** to protect your TFT display from damage resulting from **voltage surges** or **lightning**.
- To interrupt the TFT display from mains (power supply) disconnect the plug from the socket.
- To avoid power consumption when the device is switched off either pull out the power plug when the device is not used or connect the device to a master-/slave power bar.
- The power **socket** must be in the vicinity of your TFT display and within reach of the power cables. **DO NOT stretch the power cables tightly to reach a power socket**.
- If you use an **extension cable**, ensure that it fulfils the **VDE requirements**. Please ask your electrician.
- You should lay the TFT Display cables in a manner that no one can trip or step on it.
- To avoid damage of cable **do not place any objects or furniture on the cable**.
- Use a master/slave power strip to avoid consuming electricity when the equipment has been switched off.

Standards/Electro-Magnetic Compatibility

Your display fulfils the requirements for electro-magnetic compatibility and electrical safety specified in the following standards:

EN 55022, EN 55024, EN 60950, EN 61000-3-2, EN 61000-3-3
UL60950 / CAN CSA 22.2 No 60950, FCC

- When connecting ensure that Guidelines for Electro-Magnetic Compatibility (**EMC**) are observed.
- Provide an interval of at least one meter from **high-frequency and magnetic sources of interference** (television sets, loudspeakers, mobile telephones, etc.) in order to avoid malfunctions and data loss.

Ergonomics

- This display complies with all relevant regulations such as DIN EN ISO 9241-3, DIN EN ISO 9241-7 and DIN EN ISO 9241-8.
- For ergonomic reasons we suggest not to use the base-color blue on dark subfunds. This would cause bad readability and would increase eye strain.
- While working with displays you should **take breaks periodically** to avoid tension and fatigue.
- In order to save your eyes and to assure a convenient working area you should **avoid glare, reflections** and **strong contrasts** on the display. For more detailed information on workplace ergonomics, see page 9.

Electrical Safety

EN 60950	Safety of information technology equipment.
-----------------	---

- The connection of devices is limited to equipment that complies with EN60950 "Safety of information technology equipment" or EN60065 "Audio, video and similar electronic apparatus. Safety requirements"
- For U.S. / Canadian purposes: The PC should only be connected to equipment which complies with UL 60950 / CAN CSA 22.2 No 60950

Important Additional Safety Instructions

When using any electronic equipment, basic safety precautions should always be taken. Following the guidelines below can reduce the risk of fire, electric shock and injury to person:

- Do not use this product near water (e.g., near a bathtub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool).
- Avoid using a telephone/modem (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- Do not use the telephone/modem to report a gas leak in the vicinity of the leak.
- Use only the power cord indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.
- Keep batteries away from children at all times.

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Shielded interface cables, if any, must be used in order to comply with the emission limits.

Declaration of Conformity

**According to 47CFR, Parts 2 and 15 for
Class B Personal Computers:**

We: **Medion Aktiengesellschaft**_____
(Name of the Responsible Party)

Located at: **Gänsemarkt 16 – 18**_____
D-45127 Essen_____
Germany_____
(Address, City, State, Zip Code)

Fax : 0 201 / 81 081 – 227_____
(Facsimile Number **for conformity issues only**)

Declare under sole responsibility that the product identified herein, complies with 47CFR Parts 2 and 15 of the FCC rules as a Class B digital device. Each product marketed, is identical to the representative unit tested and found to be compliant with the standards. Records maintained continue to reflect the equipment being produced can be expected to be within the variation accepted, due to quantity production and testing on a statistical basis as required by 47CFR §2.909. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. The above named party is responsible for ensuring that the equipment complies with the standards of 47CFR §§15.101 to 15.109.

Trade Name: **Medion**
Type or Model Number: **MD 30422 PV**
Party Responsible: **MEDION AG**
Executed on (Date), at (Place): **18th of May, 2007, Essen**



Start-Up

Note

Before start-up always read the Chapter "**Safety and Precautions**" on page 1ff.

Mounting the Display Stand

Mount the display stand as shown in the diagram. Perform this step before connecting the display.



(III.: Mounting the display stand)

Preparations on Your Computer

If you have operated your computer previously with a CRT display, it will be necessary for you to make a few preparations. This is required when your previous display was operated with settings which are not supported by your new TFT display.

Supported Display Settings

This TFT display supports the following modes:


Resolution	Horizontal Frequency	Vertical Frequency
720 x 400	31.47 KHz	70 Hz
640 x 480	31.47 KHz	60 Hz
640 x 480	37.86 KHz	72.8 Hz
640 x 480	37.5 KHz	75 Hz
800 x 600	37.88 KHz	60.3 Hz
800 x 600	48.08 KHz	72.2 Hz
800 x 600	46.87 KHz	75 Hz
1024 x 768	48.36 KHz	60 Hz
1024 x 768	56.48 KHz	70.1 Hz
1024 x 768	60.02 KHz	75 Hz
1280 x 1024	80.00 KHz	75 Hz
1440 x 900	55.47 KHz	59.90 Hz
1680 x 1050*	64.67 KHz	60 Hz

*recommended physical resolution

Windows 9X/2000/ME/XP: Display Properties

This Windows program offers you the possibility of adapting the display to your display. This includes items such as the background image, the screen saver, the Active Desktop (Web) as well as other settings for your display and video card. The program can be started as follows:

- Right mouse click on Windows desk top and left mouse click on "**Properties**".
- Or
- Start the "Display" program in "**System control**".




(III.: Display Properties)

The resolution can be set under "**Screen resolution**" (❶). Your display can display a maximum of **1680 x 1050** image dots.

This resolution corresponds to the physical resolution. TFT displays achieve complete image quality at the physical resolution. Then click "**Color quality**" (❷) to set the color depth (number of colors displayed). Your display supports a maximum color depth of 16 million colors corresponding to 32 bit or "True Color".

The image repeat frequency can be set under "**Advanced**" (❸). A window with the characteristics of your video card appears depending on the configuration of your computer.

Under "**Adapter**" you can change the desired value in the selection field "**List All Modes...**".



Caution!

If your setting does not coincide with the values supported by your display, you may not see any image. Switch your old device on again and set the applicable values under "**Display Properties**" in accordance with the aforementioned options in this case.

Windows Vista: Display Personalitation

The integral screen has a native resolution of **1680 x 1050** pixels. If you change to a presentation with different characteristics in the Windows "**Personalization**" Help Program, the display will not appear on the whole area of the screen, among other effects.


Using a higher resolution can lead to distortion of the display, especially with text. Using a lower resolution may cause the display to use only a portion of the screen area.

You will adjust the presentation to the mode supported with the Windows "**Personalization**" Help Program.

Connecting the Display

To start using the TFT display straight away, please read the "**Safety and Precautions**" section (page 2).

We recommend that you also read all the other sections as these contain detailed explanations and tips on how to use your TFT display.



(III.: Rearside connectors)

- Ensure that the TFT display is not yet connected to the line power (power cord not yet plugged in) and neither the TFT display nor the computer is switched on.
- Prepare your computer for the TFT display if necessary with the correct settings for your TFT.

❶ Connecting Signal Cable

- Plug the data cable into the matching VGA connections on the computer and the display. If your PC also has a DVI output, you can connect your display by means of the DVI-D connector.

Note

Even if your computer offers multiple connections, connect only one cable to avoid problems with the signal detection.

❷ Connecting Audio Cable


- Plug the audio cable into the matching sockets on the computer and the TFT display.

❸ Connecting the Power Supply

- Plug the power supply cable into the power supply socket of the TFT display and plug the electric plug into a socket close to the TFT display (same circuit).
- Switch your display on using the on/off switch. Then switch on your computer.

Positioning of the Display

Please ensure that the display is set up in such a way that reflections, glare and light-dark contrast are avoided (as this will make the display less attractive to look at).



(III.: Display positioning)

Your posture

Sitting in one position for long periods can be uncomfortable. To minimize the potential for physical discomfort or injury, it's important that you maintain proper posture.

Back - While sitting at your work surface, make sure your back is supported by the chair's backrest in an erect position or angled slightly backwards.

Arms - Your arms should be relaxed and loose, elbows close to your sides, with forearms and hands approximately parallel to the floor.


Wrists - Your wrists should be as straight as possible while using the keyboard, mouse or trackball. They should not be bent sideways, or more than 10 degrees up or down.

Head - Your head should be upright or tilted slightly forward. Avoid working with your head or trunk twisted.

Legs - Your thighs should be horizontal or angled slightly downward. Your lower legs should be near a right angle to your thighs. Your feet should rest flat on the floor. If necessary, use a footrest, but double check that you have your seat height adjusted correctly before getting a footrest.

Overall - Change your position frequently and take regular breaks to avoid fatigue.

Working Ergonomics




(III.: Workplace)

- Hand's support rest: 2" – 4"
- Top line of display should keep eye's level or be a little beneath
- Eye's distance to display: 20" – 28"
- Legroom (vertical): at least 26"
- Legroom (horizontal): at least 24"

The illustration above should give you a guideline for an ergonomic workplace.

Controls



(III.: Front view controls)

Function	Description
Menu	When this key is pressed the OSD (ON screen display) starts on your TFT display Confirm you selection by pressing this key.
▼ Decrease	When OSD is active this key sets a parameter value and decreases it. Executing it directly lowers the volume. Pressing longer than 2 seconds will switch to mute.
▲ Increase	When OSD is active this key sets a parameter value and increases it. Executing it directly raises the volume. Pressing longer than 2 seconds will toggle the INPUT (VGA – DVI).
Auto	With this key you can automatically adjust the image.
⏻ Power Operation indicator	With this switch you can switch the TFT display ON and OFF. Indicates the operating state. Blue = Normal mode, Orange = Stand-by mode

Setting the TFT Display

You can set certain parameters for the TFT display on the OSD menu (ON screen display).

How to operate the OSD menu

- 1. Press the **menu key** to activate the OSD.
- 2. Select the options from the main menu with the **function selection keys** ▼/▲.
- 3. Confirm your choice with the **MENU** key.
- 4. Select the options from the sub-menu with the **function selection keys** ▼/▲.
- 5. Confirm your choice with the **MENU** key.
- 6. Set the desired value with the **function selection keys** ▼/▲.


Leaving the OSD menu

To exit the OSD menu you have different possibilities:

- Choose **Exit**.
- The OSD vanishes from the display automatically, when you do not press any key on the display during the preset time interval (factory setting is 10 seconds).

OSD Menu

The main functions and adjustment possibilities using the OSD are explained on the next pages.




(III.: OSD menu)

Note

The setting possibilities for the TFT display lead only to marginal changes due to this technology.


Picture



(III.: OSD menu - picture)

- **auto adjust**
Perform an automatic adjustment by means of the **MENU** key. The optimal values for **H. Position**, **V. Position**, **Phase** and **Clock** of your TFT screen are set automatically.
- **brightness**
Adjust the brightness of your TFT monitor with the keys **▲** and **▼**.
- **contrast**
Adjust the contrast of your TFT monitor with the keys **▲** and **▼**.
- **h. position**
Adjust the horizontal picture of the TFT monitor.
- **v. position**
Adjust the vertical picture of the TFT monitor.
- **phase**
Adjust the phase to optimize the display of your monitor.
- **clock**
Adjust the clock of the monitor. The larger the value the wider the display will appear. The lower the value the denser the display will appear.


Advanced



(III.: OSD menu - advanced)

- **sharpness**
Control the sharpness of the picture (only if the resolution is lower than 1280x1024).
- **color**
Select a general colour temperature: user, natural, warm or cool.
 - **cool**
Blue colour temperature. Predefined colour settings of the colour components red, green and blue; the colours cannot be adjusted independently of each other.
 - **fast**
Optimized for moving images as games and videos. Predefined colour settings of the colour components red, green and blue; the colours cannot be adjusted independently of each other.
 - **warm**
Red colour temperature. Predefined colour settings of the colour components red, green and blue; the colours cannot be adjusted independently of each other.
 - **sRGB**
Standard colour profile for realistic colours. Predefined colour settings of the colour components red, green and blue; the colours cannot be adjusted independently of each other.
 - **user**
Allows the independent adjustment of the colour components red, green and blue.


Audio



(III.: OSD menu - audio)

- **volume**
Set the volume of the speakers.
- **mute**
Disables the speakers.


Options



(III.: OSD menu - options)

- **OSD h position**
Adjust the horizontal position of the OSD.
- **OSD v position**
Adjust the vertical position of the OSD.

Utilities



(III.: OSD menu - utilities)

- **OSD timeout**
You can set the idle time interval, after which the OSD will vanish.
- **OSD background**
Adjust the opacity of the background of the OSD menu.
- **language**
You have several possibilities to choose the language of the OSD.

Reset

With this menu item you can reset to the factory settings. All manual adjustments are erased. All parameters now have the same values as when the unit was shipped.

Saving Energy

This display can be switched into various states of energy saving by the respective computer or operating system. This meets the current requirements for reduction of power consumption.

The display supports the following states of low energy consumption:

Status	Power Consumption	Colour of the indicator	Standby mode (approx.)
ON	< 60 W	Blue	-
OFF	< 2 W	Orange	6 seconds

The display remains – depending on the operating system – in the state of low power consumption, until you press a button of the keyboard or move the mouse (if available).

It takes approx. 6 seconds for the display to switch from **standby mode** to normal operation.

Service

Troubleshooting

If your TFT display should have problems please check if it is properly installed and plugged according to the information given in the "Start-Up" section beginning on page 5. If the problems cannot be solved, read the following chapter for possible solution.

Finding the problem

Many times, problems have simple causes. We would like to give you some tips to solve some common problems. Should these tips not help, please call us!

Check Connections and Cables

Start by carefully checking all cable connections visually. If the indicator lamps do not function, ensure that the TFT display and computer are properly connected to the line power.

Troubleshooting

No display on screen:

Check:

- **Network supply:** The network cable must rest securely in the socket and the network switch must be switched on.
- **Signal source:** Please check that the source of the signal (computer, or other source) is switched on and that the connecting cables are resting securely in the sockets.
- Image refresh frequency.
The current image refresh frequency must be suitable for the TFT display.
- Power saving mode. Press any desired key and move the mouse to deactivate the mode.
- Signal cable pins. If pins are bent, please contact your service dealer.
- Set the appropriate values for your TFT display (see "**Preparations on your computer**", page 5).

Picture runs or not stable:

Check:

- Signal cable pins. If pins are bent, please contact your service dealer.
- Signal cable pins: The plugs of the signal cable must rest securely in the sockets.
- Video card. Check whether the settings are correct.
- Image refresh frequencies. Select permissible values for your graphic settings.
- **Display output signal:** The display output signal of the computers must match the technical data of the display.
- Remove any interfering equipment (portable telephones, loudspeakers, etc.) from the vicinity of your TFT display.
- Avoid using display extension cables.

Colors not displayed cleanly:

- Check the signal cable pins. If pins are bent, please contact your service dealer.
- Readjust the corresponding settings.
- Avoid using display extension cables.

Characters displayed dark, picture too small, too large or not centered, etc.:

- Readjust the corresponding settings. (Setting TFT display, page 11)

The display is too light or too dark:

- Check that the video output level of the computer matches the technical data of the display.
- Select Auto Setup, to optimize the settings for brightness and contrast. The display should show a text page (e.g. Explorer, Word, etc.), to optimize it.

Do you require additional Support?

If the suggestions in the above section have not solved your problem, please contact the hotline. We will try and help you over the telephone. However, before you contact your Service Center, please keep the following information available:

- How is your computer configured?
- What additional peripherals do you use?
- What messages, if any, appear on your display?
- What software were you using when the error occurred?
- What steps have you already undertaken to solve the problem?
- If you have already been given a customer number, please keep this available.

Precautions


You can increase the service life of your TFT display by taking the following precautions:


Caution!
There are **no parts which can be serviced** or cleaned inside of the display housing.

- Before cleaning **always disconnect the power line** and all connection cables.
- Do **not use any solvents**, caustic or gaseous cleaning agents.
- Clean the display with a soft, lint-free cloth.
- Ensure that no water droplets remain on the display. Water can cause **permanent discoloration**.
- Do not expose the display to bright sunlight or ultraviolet radiation.

Please keep the packaging material safely and use it exclusively to transport the display.

Recycling

**Packaging**
Your device is packaged to protect it against damage during transportation. The packaging is manufactured from materials that can be sent to a specialist recycling facility and disposed of in an environmentally-friendly way.

**Device**
At the end of its life, the appliance must not be disposed of in household rubbish. Enquire about the options for environmentally-friendly disposal.

Specifications

• Visible display size	22" (55.88 cm), TFT
• Input voltage	AC 100-240 V ~ 50/60 Hz
• Power consumption	1,2 A max. 60 Watt
• Resolution	max. 1680 x 1050
• Brightness	300 cd/m ² (typ.)
• Contrast	700:1 (typ.)
• Reaction time	5ms (typ.)
• Viewing angle h/v	178°/178° (typ.)
• RGB input, analog	15-wired SUB-D connector
• RGB input, digital	DVI-D with HDCP
• User control	ON/OFF, OSD
• Ambient Temperature	Operating +41°F ~ +95°F +5° C ~ +35°C Storage -4°F ~ +140°F -20° C ~ +60°C
• Humidity	Operating < 80% Storage < 95%

Restricted Warranty

I. General Conditions of Warranty

1. General

This warranty covers defects relating to workmanship and manufacture in MEDION products. The period during which this warranty is valid and during which claims against the warranty can be made to MEDION must be in accordance with the following terms in order to be considered eligible:

- Is effective from the date of purchase or receipt of the MEDION product from an authorised seller of MEDION products; and
- expires at the end of the warranty period specified on the warranty card provided with the product.

For the warranty to be valid, you must:

- provide suitable evidence of purchase, a copy of the original purchase receipt from an authorised seller of MEDION products is preferred; or
- register your product within 28 days of purchase either online at www.MEDION.co.uk or by completing and returning the pre-paid registration card included with the product.

Please keep the original purchase receipt and the warranty card in a safe place. MEDION and its authorised sellers reserve the right to refuse a repair under warranty or a warranty confirmation if a proof of purchase [or registration of purchase] cannot be established, or has not been, submitted.

When it is necessary to return your product for repair please ensure that your product is suitably packed for transportation.

Provided that your product is still within warranty (please check the duration of the warranty period as described above) and is eligible for repair or replacement under the terms of the warranty, to return your product, please telephone MEDION on the service hotline number. You will be sent a pre-paid transportation box suitable for returning your product to MEDION. PLEASE MAKE SURE THAT YOU HAVE A BACKUP COPY OF ALL DATA ON THE PRODUCT BEFORE RETURNING THE PRODUCT TO MEDION. MEDION shall bear the costs of postage and packaging for returning the product and the transportation risk. However, if following examination of the defective product in question, MEDION, in its reasonable opinion, considers that the defect has been caused by:

- your operating and/or using the product other than as instructed in the accompanying documentation;
- damage caused in transit as a result of your negligence in packaging of the product; and/or
- otherwise than in accordance with the terms of this warranty;

This warranty shall be void and you may be required by MEDION to reimburse MEDION for the reasonable costs of postage and packaging before MEDION will return the product to you. If so and you would still like MEDION to repair or replace the product, MEDION may do so but you will be charged MEDION's standard rates for repair and replacement for this service.

Before returning the product, please contact MEDION via the service hotline or via the internet (www.MEDION.co.uk). You will receive a reference number (RMA No.) on the warranty card. Please mark the outside of your package to ensure that this reference number is clearly visible. Please submit a letter containing as much detailed information as possible and, a full description of the defect or fault.

This should include:

- a description of the fault;
- when it occurred, how long it has been evident and how frequently it occurs ;
- any errors message(s) displayed when using the product;
- a description of the circumstance(s) and conditions in which the fault occurs; and
- whether it is an intermittent or persistent fault;

This will greatly assist MEDION in identifying the defect, when submitted together with the defective product.

Unless otherwise instructed by a MEDION representative in all cases, the product must be returned complete with all parts which were included with the original product. Incomplete contents of the returned package may lead to a delay in the repair or replacement. MEDION does not accept any liability for any additionally submitted material(s) which were not supplied with the original MEDION product.

This warranty does not affect your statutory rights in any way and is subject to the applicable legal statutes of the country where the product was sold to you by an authorised MEDION seller.

2. Scope

Subject to any exclusions set out within this warranty, where there is a defect in your MEDION product covered by this warranty, MEDION will repair or replace the MEDION product. The decision whether to repair or replace the product will be made solely at the discretion of MEDION. MEDION may, in its own discretion, replace the product returned for repair under warranty with a replacement product that is either identical or, in the event that such product(s) are no longer available, a product of equal or superior specification and quality.

No warranty is given for batteries or rechargeable batteries or for consumable materials subject to wear and tear, i.e. for parts which have to be replaced periodically during the normal use of the product, such as video-projector lamp.

Non critical failures that fall within industry specified tolerances e.g. noise, LCD pixels are not covered by this warranty. Please consult the appropriate section in your user or instruction manual for this product for exact specifications and tolerances.

To the extent which is permitted under law, MEDION will accept no liability for burnt-in images on plasma or LCD products as a result of normal wear and tear during the operation of the product. Please refer to your user or instruction manual for this product for detailed operating instructions for your plasma or LCD product.

The warranty does not cover errors relating to the playback of data media in an incompatible format or created with unsuitable software.

If it is found during repair or assessment that the defect concerned is not covered under warranty, MEDION reserves the right to invoice you for all reasonable costs incurred by MEDION. These costs will be in relation to the return of the product, including reasonable administration costs, plus reasonable costs for materials used and labour provided when repairing or replacing the product. This is subject to MEDION providing you with an estimate for carrying out such work prior to costs being incurred and that you have accepted the estimate.

You are entitled to seek independent advice or consultation relating to your product or any of MEDION's findings. MEDION will not be liable for any costs incurred to you when doing so.

3. Exclusion from warranty

To the extent permitted by law, this warranty shall be void in the event that defects or loss caused by:

- a. failure and damage resulting from the operation of the product in an environment other than that recommended in the accompanying user or instruction manual (e.g. in direct sunlight or in a damp room);
- b. accidental damage;
- c. use other than in accordance with the accompanying user or instruction manual;
- d. modifications, conversions, expansions, maintenance and/or repairs made to the MEDION product by unauthorised repairers or use of unauthorised third party parts;
- e. negligence;
- f. virus attack or software errors; or
- g. improper transportation or packaging during return of the product.

This warranty will also be considered void if labels or serial numbers of the product or of a component of the product are modified or made illegible.

To the extent permitted by law, MEDION shall only be responsible for losses which are a reasonably foreseeable consequence of the relevant defect in the product; MEDION will not be responsible for any costs incurred in relation to software configuration; economic loss; loss of opportunity; loss of income; or loss of data or software arising out of its repair or replacement of a MEDION product under this warranty

4. Service Hotline

Before returning the product to MEDION you must contact us using the service hotline or via the internet (www.MEDION.co.uk). You will receive further instructions for making your claim under warranty when you call.

The service hotline is available on 362 days in the year, including Sundays and bank holidays but excluding Christmas day, New Years Day and Easter day. The service hotline is subject to [national rate] telephone call charges. These charges are subject to change. The price of your call will be stated at the beginning of the call.

II. Special warranty conditions for MEDION PC, notebook, pocket PC (PDA) and navigation devices (PNA)

The following terms apply to MEDION PC, notebook, desktop, pocket PC and laptop products and optional items included with such products. If one of these items has a fault, you also have a warranty claim for its repair or replacement, from MEDION. The warranty covers the costs of materials and labour for repairing or replacing the defective MEDION product or the optional item in question.

Hardware connected to your product that was not produced or marketed by MEDION can invalidate the warranty if MEDION can reasonably demonstrate that damage to the MEDION product or of the optional item included with the delivery was caused by such hardware. You are entitled to seek independent advice or consultation relating to your product or any of MEDION's findings. MEDION will not be liable for any costs incurred to you when doing so.

This warranty is restricted in relation to any pre-installed operating system as well as to application programme software that is included with the MEDION product in question. This warranty is restricted as follows:

For pre-installed operating system as well as to application programme software included in the MEDION product, MEDION only guarantees the data media (e.g. the diskettes and CD-ROMs) upon which this software is delivered and warrants that such data media shall be free from material and processing defects for a period of 90 days from the date of purchase of the MEDION product from an authorised seller of MEDION. MEDION will replace defective data media free of charge.

Any claims in respect of defective pre-installed operating system as well as to application programme software are hereby expressly excluded and you should contact the relevant licensor or copyright owner of the defective software in question. MEDION does not guarantee that any software supplied with MEDION products will function without interruption, will be free from errors or that it will fulfil your requirements. MEDION does not guarantee the 100% accuracy of the maps provided with the Navigation device.

It may be necessary to delete all data in the product in order to repair the MEDION product. PLEASE MAKE SURE THAT YOU HAVE A BACKUP COPY OF ALL DATA ON THE PRODUCT BEFORE RETURNING THE PRODUCT TO MEDION. To the extent permitted by law, MEDION excludes all liability for loss of data and MEDION recommends in all cases that you back up all data on your MEDION product before returning the product to MEDION.

III. Special warranty conditions for repair on site or replacement on site

If a claim for repair or replacement on site is included within the terms of the warranty card provided with the product, the special warranty conditions for repair or replacement of your MEDION product on site apply.

The following provisions must be made by you for carrying out repairs or replacements on site:

- MEDION or its authorised personnel must have unrestricted, safe and immediate access to the products.
- Telecommunication facilities required by MEDION or its authorised personnel for proper execution of your order, for testing and diagnostic purposes and for remedying faults are provided by you at your own expense.
- You are responsible yourself for restoring the application software after the repair services have been carried out by MEDION or its authorised personnel.
- You must take all other necessary steps to enable MEDION or its authorised personnel to carry out your order properly.
- You are responsible yourself for connecting and configuring any existing external peripheral products after MEDION or its authorised personnel have carried out their repairs.
- The free cancellation period for repairs or replacements on site is 24 hours, thereafter our reasonable costs resulting from late or missing cancellation shall be invoiced at your expense.

Copying this manual

This document contains legally protected information. All rights reserved. Copying in mechanical, electronic and any other form without the written approval of the manufacturer is prohibited.

Recycling Information


When customer decides to leave MEDION obsolete products for recycling from Europe, please call to the listed places in Europe.

DEUTSCHLAND / GERMANY Hellmann Process Management GmbH & Co. KG Adolf-Köhne-Str. 11 49090 Osnabrück, Germany ☎: +49 (541) 6 05 - 17 43 ☎: +49 (541) 6 05 - 45 17 43 Email: sandra.herzig@de.hellmann.net Website: http://www.hellmann-pm.de	NORWEGEN /NORWAY Danrec A/S Bogøvej 10 5900 Rudkøbing ☎: +45 6257 1118 ☎: +45 6257 1171 Email: danrec@post8.tele.dk Contact person: Mr. Stig Würtz
DÄNEMARK / DENMARK Danrec A/S Bogøvej 10 5900 Rudkøbing ☎: +45 6257 1118 ☎: +45 6257 1171 Email: danrec@post8.tele.dk Contact person: Mr. Stig Würtz	SLOWAKEI / SLOVAK REPUBLIC Arcon Slovakia s.r.o Syslia 42 821 05 Bratislava Slovak Republic ☎: +421 2 4364 2572 ☎: +421 2 4341 5489 Email: sales@arcon.sk Contact person: Stefan Melo
NEDERLANDS / NETHERLANDS Sims Mirec Dillenburgstraat 4 5605 LS Eindhoven ☎: 0031-40-2508800 Email: info@sims-mirec.com	PORTUGAL / PORTUGAL Recycling Equipos S.L Poligono Industrial Malpica, calle E. núms. 54-55 50016 Zaragoza ☎: +34 976 573 410 ☎: +34 976 572 354 Email: recycling@moros.com Contact person: Mr. Marcos Clavel
BELGIQUE /BELGIUM Umicore A. Greinerstraat 14 2660 Hoboken Thierry Van Kerckhoven ☎:0032-3-8217483 Email: Thierry.Vankerckhoven@umicore.com	FINNLAND / FINLAND Ollila & CO OY Museokatu 33 B 00100 Helsinki Finland ☎: +358 945 48 151 ☎: +358 945 48 153 Email: veikko.ollila@saunalahti.fi Contact person: Mr. Veikko Ollila
UNGARN /HUNGARY Arcon Hungary Szent István tér 7. III.em.10 H-8000 Székesfehérvár Contact person: Domonkos Balázs ☎/☎: +36 22 318 789 Email: sales@arcon.hu Mobile: +36 20 9433 405	ITALIA / ITALY: ATS Transport S.r.l. Via Fantoli 28 12 20138 Milan ☎ +39 02 580061 ☎ +39 02 58010934 E-Mail: renato.spadaro@atstransport.it

ESPAÑA / SPAIN: Hellmann Worldwide Logistics, S.A. Zona Franca Calle No 5-3a Sub-Zona 08040 Barcelona ☎: +34 93 2643870 ☎: +34 93 2643770 +34 93 2641455 +34 93 2643750 +34 93 2633892	FRANCE / FRANCE: Heppner Overseas Aéroport de Bordeaux-Mérignac Aérogare de fret - Cidex B26 33700 Mérignac Aéroport ☎: +33 556 12 42 99 ☎: +33 556 34 88 92 Email: jbbraud@fr.hellmann.net
ÖSTERREICH / AUSTRIA: Quehenberger - Hellmann Worldwide Logistics GmbH Handelszentrum 3 A-5101 Bergheim Salzburg ☎: +43 662 4680 ext. ☎: +43 662 4680 1101	UNITED KINGDOM: Hellmann Worldwide Logistics Ltd Kuhlmann House Lancaster Way Fradley Park Lichfield WS13 8SX Lichfield ☎: +44 1543 443300
TÜRKEI / TURKEY Uygun Konteyner San. Tic. Ltd. Akcesme Mah. 2031 Sok. No: 6 Gümüşler-Denizli ☎: +90 (0) - 535 653 09 95 ☎: +90 (0) - 258 371 43 78 Mobil: +90 (0) 533 649 45 02 Kontakt: Fr. Sidika Arikan	ISLAND / ICELAND HRINGTORG Álhólsvegur 100 200 Kópavogur ☎: (+354) 511 3880 ☎: (+354) 511 3881 Mobil: (+354) 820 8199 E-mail: danielh@strik.is Mr. Daniel Helgason
SCHWEIZ Cablofer Bex SA Rte Cantonale CH-1880 Bex ☎: +41 24 463 04 30 ☎: +41 24 463 04 20 Mail: cablofer@cablofer.ch	ASIEN / ASIA: Hellmann Worldwide Logistics Ltd. 1 F Blk A. No. 579 Tonic Industrial Center 26 Kai Cheung Road Kowloon Bay Kowloon HongKong ☎: +852 2796 7828
AMERIKA / USA: Hellmann Worldwide Logistics, Inc. 574 Airport South Parkway Suite 400 30349 Atlanta ☎: +770 506 2260	AUSTRALIEN SULO MGB AUSTRALIA PTY LTD 123 Wisemans Ferry Road AUS-Somersby NSW 2250 ☎: +61 (0) 2 - 4348 81 88 ☎: +61 (0) 2 - 4348 81 23 Managing Director: Mr. Huston m.huston@sulo.com.au
SLOWENIEN / SLOVENIA Intereuropa d.d. Vojkovo Nabrezje 32 6504 Koper ☎: 386 5 6641000 ☎: 386 5 6641535 Contact person : Mr. Gregar Veselko	

"THE DISPLAY UNIT IS AN ELECTRIC DEVICE WHICH MAY CONTAIN HAZARDOUS MATERIALS / COMPONENTS AND THAT IT NEEDS TO BE TAKEN CARE OF AT END OF LIFE ACCORDING TO A PROCEDURE"

TCO Development

 The image shows a blue rectangular label with white and yellow text. At the top, it says 'TcoDevelopment' in white. Below that, 'Tco'03 is written in large white and yellow letters, followed by 'DISPLAYS' in white. At the bottom, the website 'www.tcodevelopment.com' is written in white.	<h2>Congratulations!</h2> <p>The display you have just purchased carries the TCO'03 Displays label. This means that your display is designed, manufactured and tested according to some of the strictest quality and environmental requirements in the world. This makes for a high performance product, designed with the user in focus that also minimizes the impact on our natural environment.</p>
---	---

Some of the features of the TCO'03 Display requirements:

Ergonomics

- Good visual ergonomics and image quality in order to improve the working environment for the user and to reduce sight and strain problems. Important parameters are luminance, contrast, resolution, reflectance, colour rendition and image stability.

Energy

- Energy-saving mode after a certain time – beneficial both for the user and the environment
- Electrical safety

Emissions

- Electromagnetic fields
- Noise emissions

Ecology

- The product must be prepared for recycling and the manufacturer must have a certified environmental management system such as EMAS or ISO 14 000
- Restrictions on
 - chlorinated and brominated flame retardants and polymers
 - heavy metals such as cadmium, mercury and lead.

The requirements included in this label have been developed by TCO Development in cooperation with scientists, experts, users as well as manufacturers all over the world. Since the end of the 1980s TCO has been involved in influencing the development of IT equipment in a more user-friendly direction. Our labelling system started with displays in 1992 and is now requested by users and IT-manufacturers all over the world.

For more information, please visit www.tcodevelopment.com


Pixel Defects on TFTs (LCD-Displays)

Active matrix TFTs (LCD) with a resolution of **1680 x 1050 pixel (WSXGA+)**, which are in turn composed of three sub-pixels each (red, green, blue), contain **about 5.3 million** addressable transistors. Because of this very high number of transistors and their extremely complex production process occasionally defective or incorrectly addressed pixels or sub-pixels may occur.

There have been several attempts in the past to define the acceptable number of defective pixels. But this can be difficult and varies widely between different manufacturers.

MEDION, therefore, adheres to the clear and strict requirements of **ISO 13406-2, class II**, for the warranty handling of all TFT display products. These requirements are summarized below.

Within ISO-standard 13406-2 the general requirements regarding pixel defects are defined. Pixel defects are classified into three failure types and four failure classes. Each individual pixel is made up of three sub-pixels in the primary colors (red, green, blue).



Types of Pixel Failures:

- Type 1:
A constantly lit pixel (a bright, white spot), even though it is **not** addressed
A white pixel is caused when all three sub-pixel are lit.
- Type 2:
A pixel that does not light up (dark, black spot), although it is addressed
- Type 3:
Abnormal or defective red, green or blue sub-pixels.
(E.g. constantly lit with half the brightness, one color is not shining, blinking or flickering, but not belonging to Type 1 or 2 Pixel Failures)

In addition: A cluster of type 3 (= 2 or more defective sub-pixels in an array of 5 x 5 pixel). A cluster is an array of 5 x 5 pixel (15 x 5 sub-pixel).

Classes of Pixel Failures:

Failure class	Type 1	Type 2	Type 3	Cluster v. Type 3
I	0	0	0	- 0
II	2	2	5	- 2
III	5	15	50	5
IV	50	150	500	50

The acceptable number of defects of the above mentioned types in each failure class refers to one million pixels and has to be calculated according the physical resolution of the display.

This leads to a maximum **allowed** number in **class II type failure**:

Resolution	Mn Pixel	Sub-Pixel	(Type s. above)
1024 x 768 (15")	0.786432	2.359296	2 2 4 - 2
1280 x 1024 (17,18, 19")	1.310720	3.932160	3 3 7 - 3
1280 x 720 (17" wide)	0.921600	2.764800	2 2 5 - 2
1600 x 1200 (19")	1.920000	5.760000	4 4 10 - 4
1440 x 900 (19" wide)	1.296000	3.888000	3 3 7 - 3
1680 x 1050 (20" wide, 22" wide)	1.764000	5.292000	4 4 10 - 4

Class I type failure only applies to special applications, e.g. medical applications, and results in corresponding price increases. Class II type failure is the established standard for quality conscious manufacturers with high quality displays.

Example 1:

A 15" - XGA-display consists of 1024 horizontal and 768 vertical picture dots (pixel), which amounts to a total of 786,432 pixel. Related to one million pixels this translates into a factor of about 0.8.

Class II type failure consequently allows for two defects each of type 1 and type 2 and 4 defects of type 3 and 2 clusters of type 3.

Example 2:

A 17" - SXGA-display consists of 1280 horizontal and 1024 vertical picture dots (pixel), which amounts to a total of 1,31 million pixels. Based on one million pixels this translates into a factor of about 1.31.

Class II type failure consequently allows for three defects each of type 1 and type 2 and 7 defects of type 3 and 3 cluster of type 3.

These cases are normally not covered by warranty.

If the number of failures exceeds the figures of any category mentioned above then this may be covered by the warranty.

